



## Technical Data Sheet – Contico Item 1146 Dispenser Page 1 of 2

BOBSON AD300 metered control aerosol dispenser with LED indicators.

Electronically dispenses organic fragrances at an effective level 24 hours per day.

Battery operated (2 x D-cell) with a choice of 6 spray intervals. Switch option of on/off, 12 or 24 hour operation. ABS strong construction and lockable to prevent aerosol theft. Red light flashes to show operational.

Accepts Contico Kleenmist aerosols sold below.

**H: 9" (23cm), W: 4" (10cm), D: 3" (8.2cm)**

### MOUNTING

1. Use key to open cabinet and remove lock assembly. (Do not separate key from plug assembly).
2. Pull hinged cover down from top.
3. Position dispenser in desired location. Recommended height is 7 feet (2.1m), from floor and away from ventilation (one dispenser can service up to 6000 cubic feet).
4. Mark 2 holes on wall with pencil using the backplate as a template.
5. Drill marked holes with 3/16 drill.
6. Insert plastic anchors provided and push completely into holes.
7. Turn screws in anchors, leaving enough clearance for thickness of dispenser wall.
8. Select the desired operation mode with 3 inner switches.
9. Insert new aerosol refill.
10. Insert two (2) D-cell batteries into unit (alkaline batteries recommended for longer usage).
11. Close cover. Unit is now in ON mode and a blinking red light will indicate. Unit will run self-testing for one spray automatically. Do not stand in front of dispenser in order to avoid spraying on to face.
12. Lock cover (for lockable type).

This data sheet has been created based on general information required by customers and data supplied by our manufacturers. The information given is to the best of our knowledge correct and will be updated when required by legislation or upon specific request. If further details are required please contact our Customer Services or your Contico Sales Manager. Due to the high demand for legislation information (WEEE, EEE, REACH, COSCH, Package and Waste, etc) and to conform to the parameters of ISO 9001, all relevant information can now be downloaded from the Contico web-site: [www.conticospraychem.com](http://www.conticospraychem.com).

Please let us know by e-mail if you require further product information and we will endeavour to supply/upload the information to our web-site.

If you order products via the web-site, we also offer you the facility to download your own Package & Waste statistics.

If you have any other questions, please do not hesitate to contact us.

### **SETTING**

1. Select the desired operation mode with 3 inner switches.

- |            |           |    |      |
|------------|-----------|----|------|
| 2. STEP 1: | OFF       | 12 | 24   |
| STEP 2:    | A         | B  | DEMO |
| STEP 3:    | T setting |    |      |

#### **OFF 12 24**

OFF: Stop operation  
12: Runs 12 hours/day  
24: Runs 24 hours/day

#### **A B DEMO**

A: To select interval timer T1, T2, T3  
B: To select interval timer T4, T5, T6  
DEMO: Self-testing - sprays every 5 seconds.

#### **T Setting**

Please refer to the inner label for TIMER CYCLE and DAYS.

3. Insert new aerosol refill.
4. Insert two (2) D cell batteries into unit (alkaline batteries recommended for longer usage).
5. Close cover. Blinking red light indicates unit is in ON (operation) mode. Unit will run self-testing for one spray after a long-beep warning tone. DO NOT SPRAY INTO EYES.
6. Lock cover (for lockable type).

### **CAUTION:**

Keep away from unit. When set to DEMO, the unit will continuously spray every 5 seconds following two 2 short beep warning tone.